


ASSEMBLY INSTRUCTIONS


## **VARIOCAGE**

double - divider


STEP  
**1**




**K** Divider Door






**J** Divider Escape Hatch



STEP  
**2**



Do not tighten screws in panel yet.  
This will be done in the nex step.

M-SM6X14IA 4X 	M-BR6X19X1S 4X Ø19mm 	M-B251,56,5SLD 4X Ø25mm 
---	---	--


STEP  
**3**

Divider is fixed in the doors center post.  
On the other side at the emergency hatch there is 3 positions to choose from, Left, Center and Right.


**Option A**  
Angled divider



TOP VIEW




Door




If you got different size of dogs  
they might need different size of  
room in the cage.  
Use the Left or Right position  
for the Divider.

**Option B**  
Straight divider



Front








If you got same size of dogs they  
could have equal size of room in  
the cage.  
Use the Center position  
for the Divider.

STEP  
**3a**

## Option A






Angled divider



STEP  
**3<sub>b</sub>**

## Option B

Straight divider



**IMPORTANT** - Find the complete assembly instructions for VarioCage double at [www.mimsafe.com](http://www.mimsafe.com) for more information.